



Setting menu / Einstellungs Menü / Menu réglages

MC 10 13:30 → x 1 → Trip Dist 000 → Press and hold for 4 sec. → Settina OPEN → Enalish

Set language / Sprache einstellen / Sélectionner la langue

English → Deutsch

Enalish → x 1 → Enalish → x 6 → Deutsch → x 1 → Set Ok → Deutsch

→ Press mode button to advance to wheel size setting, or SET button to see "Setting CLOSE" step to exit.

Set wheel size / Eingabe Radumfang / Réglage de la circonference de la roue

1880 → 1836

Wheelsize 1880 → x 1 → Wheelsize 1880 → x 1 → Wheelsize 1880 → x 5 → Wheelsize 1830 → x 1 → Wheelsize 1830 → x 6 → Wheelsize 1836 → x 1 → Set Ok → Wheelsize 1836

→ Press mode button to advance to Unit of measurement setting, or SET button to see "Setting CLOSE" step to exit.

Set Unit of Measurement / Einheit festlegen / Définir l'unité

KMH → MPH

Unit KMH → x 1 → Unit KMH → x 1 → Unit MPH → x 1 → Set Ok → Unit MPH

→ Press mode button to advance to Clock setting, or SET button to see "Setting CLOSE" step to exit.

Set clock / Uhrzeit einstellen / Régler l'heure

00:00 → 15:36 (Note: KMH = 24h clock, MPH = 12h clock)

Clock 0000 → x 1 → Clock 0000 → x 15 → Clock 1500 → x 1 → Clock 1500 → x 36 → Clock 15:36 → x 1 → Set Ok → Clock 15:36

→ Press mode button to advance to total distance setting, or see "Setting CLOSE" step to exit.

Set total distance / Gesamtstrecke einstellen / Régler la distance totale

0 → 2325

Tot Dist 0 → x 1 → Tot Dist 00000 → x 1 → Tot Dist 00000 → x 2 → Tot Dist 02000 → x 1 → Tot Dist 02000 → x 3 → Tot Dist 02300 → x 1 → Tot Dist 02300 → x 2 → Tot Dist 02320 → x 1 → Tot Dist 02320 → x 5 → Tot Dist 02325 → x 1 → Set Ok → Tot Dist 2325

Set total time / Gesamtzeit einstellen / Régler la durée totale

0 → 105:40

Tot Time 000 → x 1 → Tot Time 00000h → x 1 → Tot Time 00000h → x 1 → Tot Time 0.100h → x 1 → Tot Time 0.100h → x 1 → Tot Time 0.100h → x 5 → Tot Time 0.105h → x 1 → Tot Time 00min → x 40 → Tot Time 40min → x 1 → Set Ok → Tot Time 10540

Exit Setting Menu / Einstellungs Menü schließen / Fermez le menu réglages

Tot Time 10540 → Press and hold for 4 sec. → Settina CLOSE → Trip Dist 000

Reset / Nullstellen / Réinitialiser / Azzeramento

15:38 → 0.00

Trip Dist 15:38 → Press and hold for 4 sec. → Tour Data RESET → Trip Dist 000

GB US You can find the CE declaration under: www.sigmasport.com

Start-up:
Your bike computer comes in "deep sleep mode". To exit this mode, please press and hold the SET button for five seconds. On waking up, the bike computer will be in active mode.

Button functions:

MODE button for:

- Switching between functions
- Deleting current values
- Changing the values in the settings mode

SET button for:

- Switching to/from the settings mode
- Confirming settings

Display layout:

Top field: Speed
Middle field: Description of the functions
Bottom field: Current value

Wheel size determination:
To measure the speed precisely, the wheel size must be set according to your tire size. To do this, see graphic:

Measuring the wheel size

Description of functions:

- Hide functions during the trip → the total values (total distance/total time) are hidden while your bike is in motion. Only the information for the current ride will be displayed. This decreases the number of times you have to press a button to see the information that matters most on your ride.

Troubleshooting:

No Speed, or incorrect speed displayed:

- Was the metal sleeve installed over the magnet?
- Computer fully twisted into mount? (is "SIGMA" on the mount facing forward?)
- Distance to magnet and sensor checked?
- Two magnets mounted? (Or did you put your front wheel on backwards?)
- Magnet correctly positioned in relation to the sensor?
- Wheel circumference correctly set?

More troubleshooting solutions can be found in our FAQs at www.sigmasport.com

Technical data:

- Battery type: CR 2032, 3V
- Battery life: MC 10, 3 years*
- (*when used for one hour per day)

Warranty:
We are liable to our contracting partners for defects in line with legal provisions. The warranty does not extend to batteries and wear-and-tear parts. In the event of a warranty claim, please contact the retailer from whom you purchased your bike computer. You can also send your bike computer, together with your receipt and all accessories, to the following address. Please ensure you pay sufficient postage.

SIGMA-ELEKTRO GmbH
Dr.-Julius-Leber-Strasse 15
D-67433 Neustadt an der Weinstrasse
Service tel.: ++49-(0) 63 21-91 20-118
E-mail: service@sigmasport.com

In the event of justified warranty claims, you will receive a replacement device. You will only be entitled to the model available at the time of replacement. The manufacturer retains the right to make technical modifications. SIGMA-ELEKTRO GmbH hereby declares that the wireless bike computers comply with the fundamental requirements and other relevant regulations of Directive 1999/5/EC.

DE Sie finden die CE-Erklärung unter folgendem Link: www.sigmasport.com

Inbetriebnahme:
Im Lieferzustand befindet sich der Fahrradcomputer in einem sogenannten Tiefschlafmodus. Um diesen Modus verlassen zu können, bitte die SET-Taste für 5 Sekunden lang gedrückt halten. Nach dem Erwachen befindet sich der Fahrradcomputer im aktiven Modus.

Tastenbelegung:

MODE-Taste zum:

- Wechseln der Funktionen
- Löschen der aktuellen Werte
- Ändern der Werte im Einstellungsmodus

SET-Taste zum:

- Wechseln im/aus dem Einstellungsmodus
- Bestätigen der Einstellungen

Display Aufbau:

Oberes Segmentfeld: Geschwindigkeitsanzeige
Mittleres Segmentfeld: Beschreibung der Funktionen
Unteres Segmentfeld: Aktueller Wert

Radgrößenbestimmung:
Um die Genauigkeit der Geschwindigkeitsmessung zu erreichen, muss die Radgröße entsprechend Ihrer Reifengröße eingestellt werden. Sehen Sie hierzu die Grafik:

Radgröße messen

Funktionsbeschreibung:
– Ausblenden von Funktionen während der Fahrt → Die Gesamtwerte sind während der Fahrt (sobald eine Geschwindigkeitsangabe vorliegt) ausgeblendet. So müssen Sie weniger Funktionen durchklicken.

Problemlösung:

Keine oder falsche Geschwindigkeitsanzeige:

- Hülse über Magnet geschoben?
- Computer richtig in der Halterung eingerastet?
- Abstand zu Magnet und Sensor überprüft?
- 2 Magnete montiert?
- Magnet zum Sensor richtig positioniert?
- Radumfang richtig eingestellt?

Weitere Problemlösungen erhalten Sie aus unseren FAQ unter www.sigmasport.com

Technische Daten:

- Batterietyp: CR 2032, 3V
- Batterielebensdauer: MC 10, 3 Jahre*
- (*Bei einer Benutzung von 1 Stunden pro Tag)

Garantiebestimmungen:
Wir haften gegenüber unserem jeweiligen Vertragspartner für Mängel nach den gesetzlichen Vorschriften. Im Falle der Gewährleistung wenden Sie sich bitte an den Händler, bei dem Sie Ihren Fahrradcomputer gekauft haben. Sie können den Fahrradcomputer mit Ihrem Kaufbeleg und allen Zubehörteilen auch an die nachfolgende Adresse senden. Bitte achten Sie auf ausreichende Frankierung. Ein Anspruch auf Garantie besteht bei Material- und Verarbeitungsfehler. Von der Garantie ausgenommen sind Batterien, Verschleißteile und Verschleiß durch gewerbliche Nutzung oder Unfälle. Der Anspruch auf Garantie besteht nur, wenn das eigentliche SIGMA Produkt nicht eigenmächtig geöffnet wurde und der Kaufbeleg beigelegt ist.

SIGMA-ELEKTRO GmbH
Dr.-Julius-Leber-Strasse 15,
D-67433 Neustadt/Weinstraße
Tel.: +49-(0) 63 21-91 20-1 18, Fax.: +49-(0) 63 21-91 20-34
E-Mail: service@sigmasport.com

Bei berechtigten Ansprüchen auf Gewährleistung erhalten Sie ein Austauschgerät. Es besteht nur Anspruch auf das zu diesem Zeitpunkt aktuelle Modell. Der Hersteller behält sich technische Änderungen vor. Hiermit erklärt SIGMA-ELEKTRO GmbH, dass sich die kabellosen Fahrradcomputer in Übereinstimmung mit den grundlegenden Anforderungen und den anderen relevanten Vorschriften der Richtlinie 1999/5/EG befinden.

